























































Feature operation

AutoDial			
Store	AutoDial 		AutoDial 
Use		AutoDial 	
Display	Display 	AutoDial 	
Call Forward			
Activate	Fwd 		
Deactivate			
Reinstate	Fwd 		
View number	Display 		
Call Pickup			
		Pickup	
Call Waiting			
Answer	 (Hold)	Call Waiting	
Return to first call	 (Goodbye)		
Conference			
	Conf 		
Handsfree			
Activate	 (Handsfree)	 (Goodbye)	(to end the call)
Switch to handset			
Handset to handsfree	 (Handsfree)		
Activate Headset			
	 (Headset)	 (Goodbye)	(to end the call)
Hold			
Place a call on hold	 (Hold)		
Return to a held call			
Last Number Redial			
			
Message			
		 (Msg/Inbox)	
Ring Again			
Activate	RngAgn 		
When notified			
Deactivate			
Transfer			
	Trans 		
Adjust volume			
	 (Volume +)	or  (Volume -)	

Legend

Icon	Action
()	Indicates the key cap text label. For example, (Message).
	Lift the handset, press the line (DN) key or the Headset key.
	Replace the handset, or press  (Goodbye) to end the call.

Legend (continued)

Icon	Action
	Press a line/feature key.
	Dial a number.
	An icon flashes when a feature is being programmed. An icon lights steadily when a feature is active.
	Press the Services key once for Call Platform features, or press the Services key twice for local phone features.
	Press the Message/Inbox key.
	Press the Up/Down Navigation keys
	Press the Enter key
	Press the Headset key.
	Press the Handsfree key.
	Press the Mute (on/off) key.
	Press the Directory key.
	Press the Quit/Stop key.

Services and Telephone Options menus

Services menu



Note: The **Services** menu contains the **Telephone Options**, **Password Admin**, **Virtual Office**, and **MG 1000B** menus. These options are not available on all Nortel IP Phone 1120E phones. Consult your system administrator.

The following are the most commonly used options:

Telephone Options menu

Volume adjustment

Pick one of:

Ringer
Handset Listen
Handsfree Listen
Headset Listen
Buzzer



Contrast adjustment



Language



Note: This language setting controls the language used by features on your phone only. To set the language used elsewhere on your phone, press **Services** twice, select 1. Preferences, and select 2. Language.

Date/Time format



Local DialPad Tone



Ring type



OnHook default path



Note: The **Directory** key provides access to Corporate Directory, Personal Directory, Redial List, and Callers List. For additional information about your IP Phone 1120E, consult the *Nortel IP Phone 1120E User Guide* (NN43112-103).

Nortel IP Phone 1120E



*Note: If supported by your server, the data message waiting indicator provides a data alert. Contact your system administrator to find out if this feature is available for you.

NORTEL

www.nortel.com

IP Phone 1120E

For Nortel Communication Server 1000

Quick Reference Card



Date: May 2007

Document Release: Standard 01.01

Document Number: NN43112-101

Copyright © 2006–2007 Nortel Networks.

All Rights Reserved.

* Nortel, the Nortel logo, and the Globemark are trademarks of Nortel Networks.